



Quick Start Instructions

Preparing your new Aquabot to clean your pool is as easy as 1,2,3!


1. Lock the Floating Handle diagonally across the Aquabot's body.



2. Plug the Floating Cable into the Power Supply (the Power Supply should be placed at least 12 feet from the edge of the pool). Spread the Floating Cable evenly over the pool's surface.



3. Plug the Power Supply into a GFCI grounded 115V outlet. *Never leave the Power Supply plugged in when the Aquabot is not in use.*



That's it! Your Aquabot is ready to go!

Simply place the Aquabot into the pool and while holding the Floating Handle, gently rock it back and forth under the water to allow trapped air to escape. Then let go and it will settle to the pool bottom (make sure that the cleaner is resting level on the pool floor). Now, just switch on the Power Supply and watch the Aquabot clean your pool! *NOTE: Some Aquabot Models' Power Supplies are equipped with Timer Reset Switches which must be pressed each time you turn on the pool cleaner. The Reset Switch prevents the Aquabot from unintentional, "out of water" starts due to power surges or accidental pressing of the Power Supply On/Off Switch, which would damage the cleaner.*

Warning! A ground fault circuit interrupter (GFCI) must be installed to protect your electrical outlet and to prevent any possible electrical shock.

Contents

Operating Features	2
Quick Start Instructions	3
Locking the Floating Handle	4
Locating the Power Supply	4
Setting The Timer	4
Remote Control Operation	5
Filter Bag Maintenance	5
Floatation, Propeller and Cable Care	6
Brush and Drive Track Replacement	7
Drive Belt Replacement	8
Troubleshooting Guide	9-14
Using the E-Z Swivel Cord Detangler	15